

MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH
 ZIEGELTALSTRASSE 2
 D-93346 IHRLESTEIN
 TELEFON 09441-176940
 TELEFAX 09441-1769499
 www.moellerstonecare.eu
 info@moellerstonecare.eu



MOELLER STONE CARE

SOLNHOFENER TILES

TI-2.2

– fine honed – polished –

Care instruction tested to DIN 18332 (EN 12440)

CONDITIONS

When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content).

Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed.

Drying times are indicative only and are subject to variation depending on the weather and the object and can be longer.

It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent.

Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

CLEANING

Construction dirt: **R155 Intensive Cleaner** - acid free Coverage: approx. 10-80 m²/litre

Stains: Refer to Technical Information Sheet No. 1

After cleaning the surface must be allowed to dry for at least 1 to 2 days to a residual moisture content of 2-4% before any further treatment can take place.

PROTECTION

Without enhancing colour: **S232 Stain Protection** - water based (inside and outside) Coverage: approx. 5-20 m²/litre

Minimal colour enhancing: **S234 Stain Protection** - extra (inside and outside) Coverage: approx. 5-20 m²/litre

Strong colour enhancing: **S244 Colour Enhancer** - extra (inside and outside) Coverage: approx. 5-20 m²/litre

Once dry the residual material is not harmful to health. Therefore impregnators can be used on kitchen tops.

MAINTENANCE – inside and outside

Regular maintenance: **P324 Liquid Stone Soap** - no rinse (natural product)
add approx. 25-50 ml for every 10 liters of wash water

Strong loaded surfaces: **P319 Marble and Granite Polish**
-only for inside-
add approx. 100-200 ml for every 10 liters of wash water,
that means five times using P324, than one time using P319.

OLD SURFACES

Films of maintenance products and dirt: **R155 Intensive Cleaner** - acid free Coverage: approx. 10-80 m²/litre

Layer of Waxes: **R154 Stripper - Stain Remover** Coverage: approx. 5-10 m²/litre

For optimum results and durability of further applications, older surfaces should be thoroughly cleaned. Repeat cleaning if necessary. After necessary drying time is allowed, proceed with products indicated under „PROTECTION“. Always follow individual product directions.

ENVIRONMENT

All specialist products comply with the German Detergent Act and are registered with the Federal Environmental Offices in Berlin.

Our specialized products have been recommended for decades by leading natural stone producers.

This technical instruction card is for advice only and is supplied without obligation. We require that the person making the application adapts all data concerning the application of the products to local conditions and the materials to be cleaned. We reserve the right to make changes to our products without warning as a result of technological advancement. The person conducting the application is responsible for any third person liabilities and ensuring compliance with any local laws or regulations.

Your local dealer:

All products are available from many reputable natural stone and tile dealers.