

MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH
 ZIEGELTALSTRASSE 2
 D-93346 IHRLERSTEIN
 TELEFON 09441-176940
 TELEFAX 09441-1769499
 www.moellerstonecare.eu
 info@moellerstonecare.eu



MOELLER STONE CARE

ANTIQUÉ MARBLE

TI-3.3

– untreated matte –

Care instruction tested to DIN 18332 (EN 12440)

CONDITIONS

When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content).
 Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed.
 Drying times are indicative only and are subject to variation depending on the weather and the object and can be longer.
 It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent.
 Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

HELP FOR GROUTING

Before grouting: **S245 Joint Protector** - water based Coverage: approx. 10-15 m²/litre

CLEANING

Construction dirt: **R155 Intensive Cleaner** - acid free Coverage: approx. 10-80 m²/litre
Cement smears: **R183 Cement Film Remover for Natural Stone** Coverage: approx. 5-30 m²/litre
Stains: Refer to Technical Information Sheet No. 1

After cleaning the surface must be allowed to dry for at least 1 to 2 days to a residual moisture content of 2-4% before any further treatment can take place.

PROTECTION – inside

Pre-treatment: **P335 Antique Marble Paste** - light Coverage: approx. 5-10 m²/litre
 maybe two applications necessary
 after drying time (round 48 hours) make finishing
P336 Antique Marble Paste - dark Coverage: approx. 5-10 m²/litre
 maybe two applications necessary
 after drying time (round 48 hours) make finishing
Finishing: **P337 Antique Marble Finish Wax** Coverage: approx. 5-15 m²/litre

MAINTENANCE – inside

Regular maintenance: **P324 Liquid Stone Soap** - no rinse (natural product)
 add approx. 25-50 ml for every 10 liters of wash water
Gloss retention: **P337 Antique Marble Finish Wax**
 per loading and stress re-grow sometimes.

OLD SURFACES

Films of maintenance products and dirt: **R155 Intensive Cleaner** - acid free Coverage: approx. 10-80 m²/litre

For optimum results and durability of further applications, older surfaces should be thoroughly cleaned. Repeat cleaning if necessary. After necessary drying time is allowed, proceed with products indicated under „PROTECTION“. Always follow individual product directions.

ENVIRONMENT

All specialist products comply with the German Detergent Act and are registered with the Federal Environmental Offices in Berlin.

Our specialized products have been recommended for decades by leading natural stone producers.

This technical instruction card is for advice only and is supplied without obligation. We require that the person making the application adapts all data concerning the application of the products to local conditions and the materials to be cleaned. We reserve the right to make changes to our products without warning as a result of technological advancement. The person conducting the application is responsible for any third person liabilities and ensuring compliance with any local laws or regulations.

Your local dealer:

All products are available from many reputable natural stone and tile dealers.