

MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH
ZIEGELTALSTRASSE 2
D-93346 IHRLEINSTEIN
TELEFON 09441-176940
TELEFAX 09441-1769499
www.moellerstonecare.eu
info@moellerstonecare.eu

MOELLER STONE CARE



PRODUCT SPECIFICATION

HMK® R764 - ANTI-SLIP - porcelain tiles FOR PROFESSIONAL USE

- **increases slip resistance**

HMK® R764 is a special ready to use product that increases slip resistance on porcelain surfaces and unglazed ceramic tiles. HMK® R764 creates microscopic pores in the surface that work on wet surfaces to restrict slipping and sliding. Before beginning application test the product on a sample tile or in an inconspicuous place to evaluate the effectiveness and suitability.

Note: Improper application such as allowing foam to develop and uneven application will require mechanical refinishing. The gloss and color of the surface will be altered with this treatment. Do not apply in direct sunlight. Acid sensitive surfaces, metals, plastics, glass etc... will be damaged by contact with HMK® R764.

Instructions: Protect adjacent surfaces and ensure the working area is well ventilated. If under-floor heating exists switch it off and allow the surface to cool. Clean the surface to be treated thoroughly using HMK® R155 Intensive Cleaner - acid free or stripped with HMK® R154 Stripper - Stain Remover (see product specifications for details). Once the surface has dried to the touch apply HMK® R764 undiluted evenly and generously with a sponge or a wash mop. Do not allow foam to develop or HMK® R764 to dry until the procedure is completed (approx. 5-20 minutes). After the process is completed wash the surface thoroughly using HMK® R155 Intensive Cleaner - acid free diluted 1:20 with clean water. Rinse the treated surface thoroughly with clear water at the end of the process. Repeat the treatment process if slip resistance needs to be further enhanced.

When using a wet vacuum we recommend that you add to the water HMK® Z702 Defoamer to regulate the amount of foam.

Coverage: About 20-30 m²/litre.

Warning: Highly toxic and corrosive. Poisonous. Contains ammonium hydrogen difluoride. Avoid eye/skin contact. Wear suitable protective clothing. If exposed, wash/flush with water and seek medical attention. Keep out of the reach of children. See Material Safety Data Sheet for more detailed information.

Packaging: 12 x 1 litre bottles/box

Storage: Store in a cool place.

Testing: Always test the product in an inconspicuous area to evaluate suitability, coverage and performance. Do not use the product in temperatures below 12° and above 25°C.

Limitation of liability: The liability of HMK® Moeller Stone Care for defective products and any claims for damages whatsoever is limited to the purchase price of the products. HMK® Moeller Stone Care shall not be liable for any consequential damages. No other warranty or representation is made or implied.